

Installation Manual



Notes

- Make sure you have all the tools and accessories required to complete the installation correctly.
- These products are designed for connection to a 100-240V AC 50/60Hz supply.
- Any broken or damaged parts should be replaced as soon as possible.
- Always disconnect power before installation or servicing.
- Mondolux will not accept responsibility for any claims arising from a poor installation.

Installation Steps

1. Check you have all the tools and accessories required to complete the installation correctly.
2. Use measurements between the holes of bracket as a guide and drill mounting holes.
3. Loosen bracket securing bolts from luminaire so the bracket is loose enough to rotate by hand.
4. Rotate the bracket 90°.
5. Fix luminaire using suitable fixings (not supplied) for application.
6. Once mounted, adjust the luminaire to desired angle and secure the bracket securing bolts.
7. Connect the mains input cable as indicated in below diagram using a suitable connector/ junction box to maintain the IP rating of the connection.
8. Turn on power supply and test for correct operation.

Wiring Instructions

100-240V AC 50/60Hz / Class I

Note: Class I products must always be Earthed/Grounded

